



Motorcycle Manufacturer	aprilia
Model	ATLANTIC 125/200
Year	
Issue	05/03 Rev. 00

Recommended siting	Secure the alarm unit behind the instrument panel, under the front shield.
Power supply	Connect the positive supply wire of the security system to the ORANGE/RED wire found in the white 2-way connector that is attached to the harness coming out of the ignition lock. Connect the negative supply wire of the security system to the BLUE wire of one of the front turn indicators.
Engine immobilisation (1)	Follow diagram B. Cut the WHITE/BLACK wire available in the white 6-way connector that is attached to the harness coming out of the right switch, behind the headlamp.
Engine immobilisation (2)	Cut the YELLOW/RED wire found in the white 6-way connector that is attached to the harness coming out of the right switch, behind the headlamp.
Ignition controlled positive supply	Connect to the GREEN/YELLOW wire found in the white 2-way connector that is attached to the harness coming out of the ignition lock.
Turn indicators	Connect to the LIGHT BLUE and RED wires found in the white 6-way connector that is located behind the headlamp.