



<b>Motorcycle Manufacturer</b>	<b>aprilia</b>
<b>Model</b>	<b>ATLANTIC 500 cc</b>
<b>Year</b>	
<b>Issue</b>	<b>03/02 Rev. 00</b>

<b>Recommended siting</b>	Secure the alarm unit on the voltage regulator. Use one of the two free holes in the small bracket that is soldered to the frame under the rear fairing, behind the compartment under the seat.
<b>Power supply</b>	Connect the positive and the negative supply wires of the alarm system directly to the positive and negative terminals of the battery.
<b>Engine immobilisation (1 and 2)</b>	Cut the YELLOW/RED wire found in the white 2-way connector that is attached to the starter solenoid, on the right of the battery.
<b>Ignition controlled positive supply</b>	Connect to the GREEN wire found in the white 2-way free connector located under the rear fairing on the right of the regulator.
<b>Turn indicators</b>	Connect to the LIGHT BLUE and RED wires found in the white 6-way connectors of the tail lights.