



Motorcycle Manufacturer	aprilia
Model	HABANA 50 cc
Year	//
Issue	03/00 – rev. 00

Recommended siting	Install the alarm system behind the front shield, in front of the horn.
Power supply	Connect the positive supply wire of the alarm system to the ORANGE wire available in the white 2-way connector of the wiring loom coming out of the ignition lock. Connect the negative supply wire of the alarm system to an earth bolt on the car chassis.
Engine immobilisation (1)	Follow Diagram B. Cut the RED/BLACK wire available in the white 2 -way connector of the wiring harness coming out of the ignition lock.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the loom coming down from the handlebar.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the white 2-way connector of the wiring harness coming out of the ignition lock, the same wire as used for engine immobilisation 1.
Turn indicators	Connect to the LIGHT BLUE wire and RED wire available directly on the front turn indicators.