

Motorcycle Manufacturer	aprilia
Model	RSV 1000 / TUONO
Year	//
Issue	05/03 Rev. 01

Recommended siting	Install the alarm system on the rear frame, behind the left fairing.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the positive and to the negative terminals of the battery.
Engine immobilisation (1)	Follow Diagram B. Cut the GREEN/RED wire available in the white 4-way connector on the fuel pump relay, placed under the seat (the first relay on the left).
Engine immobilisation (2)	Cut the YELLOW/RED wire of the white 2-way connector on the wiring loom coming out of the starter solenoid, under the front seat.
Ignition controlled positive supply	Connect to the GREEN/RED wire available in the white 4-way connector on the fuel pump relay, placed under the seat (the first relay on the left). This is the same wire as used for the engine immobilisation (1).
Turn indicators	Connect to the LIGHT BLUE and RED wires available in the white 2-way connectors placed under the seat. These connectors are in the wiring loom that powers the rear turn indicators.