




Motorcycle Manufacturer	
Model	QUADRA/CHRONO
Issue	10/95 – rev. 00

Recommended siting	Behind the front shield, in the upper part of the tool-box, on the left side.
Power supply	Connect the positive supply wire of the alarm system to the GREEN/BLACK wire and the negative supply wire to the BLACK wire of the ignition lock.
Engine immobilisation (1)	Follow diagram A. Connect to the WHITE/BLACK wire of the ignition lock.
Engine immobilisation (2)	Connect to the RED/PINK wire of the 4-way connector coming from the instruments.
Ignition controlled positive supply	Connect to the BLUE wire of the ignition lock.
Turn indicators	Connect to the VIOLET and GREEN wires of the 9-way connector coming from the instruments.