




<b>Motorcycle Manufacturer</b>	
<b>Model</b>	TEMPO 50
<b>Issue</b>	6/94 – rev. 00

<b>Recommended siting</b>	Behind the front shield, in the upper part of the tool-box, on the left side.
<b>Power supply</b>	Connect the positive supply wire of the alarm system to the ORANGE wire and the negative supply wire to the BLUE wire of the ignition lock.
<b>Engine immobilisation (1)</b>	Follow diagram A. Connect to the WHITE/RED wire of the ignition lock.
<b>Ignition controlled positive supply</b>	Connect to the GREEN wire of the ignition lock.
<b>Turn indicators</b>	Connect to the VIOLET and GREEN wires of the 9-way connector placed behind the shield.