

Motorcycle Manufacturer	bimota
Model	DB 4
Year	//
Issue	04/2000 Rev. 00

Recommended siting	Install the alarm system under the left fairing (the frame is threaded).
Power supply	Connect the positive supply wire of the alarm system to the GREEN wire available in the black 4-way connector that is secured on the right of the headlamp. Connect the negative supply wire of the alarm system to the BLACK wire available in the bullet connector on the right front turn indicator.
Engine immobilisation (1)	Follow diagram B. Cut the WHITE/BLACK wire available in the grey 6-way connector located under the rev counter.
Engine immobilisation (2)	Cut the GREEN wire available in the grey 6-way connector located under the rev counter.
Ignition controlled positive supply	Connect to the ORANGE wire available in the black 4-way connector on the right of the headlamp.
Turn indicators	Connect to the LIGHT BLUE wire and RED wire with bullet connectors of the front turn indicators.