


Motorcycle Manufacturer	
Model	F 650
Issue	6/95 – rev. 00

Recommended siting	Under the instrument panel, on the left side.
Power supply	Connect the positive supply wire of the alarm system to the WHITE/RED wire of the 4-way connector of the ignition lock. Connect the negative supply wire to the BROWN wire of the 2-way connector of the front right turn indicator.
Engine immobilisation (1)	Follow diagram B. Cut the RED wire with an individual connector under the connector support.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/BLACK wire of the 6-way connector of the right switch.
Ignition controlled positive supply	Connect to the GREEN/BLACK wire of the 6-way connector of the right switch.
Turn indicators	Connect to the BLUE/BLACK wire and RED/BLUE wire of the 9-way connector of the left switch.