


Motorcycle Manufacturer	
Model	F 650 GS CS Year 2000
Issue	05/01 – rev. 00

Recommended siting	Install the alarm system under the plastic wall with a lock, behind the tail light.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the positive and negative terminals of the battery.
Engine immobilisation (1)	Follow diagram B. Cut the GREEN/BROWN wire available in the black 2-way connector of the fuel pump, located under the seat, behind the CDI.
Engine immobilisation (2)	Cut the YELLOW/BLACK wire of the starter solenoid.
Ignition controlled positive supply	Connect to the GREEN wire available in the fuse-box, on the right of the CDI, under the front seat.
Turn indicators	Connect to the BLUE/BLACK wire and to the BLUE/RED wire available in the black 6-way connector on the right of the CDI, under the front seat.