


Motorcycle Manufacturer	
Model	R 850 R
Year	//
Issue	04/99 – rev. 00

Recommended siting	<p><u>Models with ABS:</u> Secure the alarm system over the filter box, under the front seat.</p> <p><u>Models without ABS:</u> Install the alarm system under the fuel tank, between the battery and the electronic control unit.</p>
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery.
Engine immobilisation (1) and (2)	Follow diagram B. Cut the GREEN/RED wire available in the white 12-way connector that is located under the fuel tank, over the coil.
Ignition controlled positive supply	Connect to the GREEN wire available in the orange 8-way connector found under the fuel tank, over the coil.
Turn indicators	Connect to the BLUE/BLACK wire and to the BLUE/RED wire available in the white 12-way connector found under the fuel tank, over the coil.