


Motorcycle Manufacturer	
Model	R 850 / 1100 (all versions)
Year	//
Issue	01/99 – rev. 00

Recommended siting	Behind the tail light, under the fairing.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery.
Engine immobilisation (1)	Follow diagram B. Cut the GREEN/RED wire available in the black 2-way connector placed under the seat, behind the left fairing.
Engine immobilisation (2)	Cut the BLACK/YELLOW wire of the starter relay (brown relay) located inside the fuse-box, under the seat.
Ignition controlled positive supply	Connect to the GREEN wire of the ABS relay located inside the fuse-box, under the seat.
Turn indicators	Connect to the BLUE/BLACK wire and to the BLUE/RED wire available directly on the flasher unit, inside the fuse-box, under the seat.