


Motorcycle Manufacturer	
Model	R 1100 / GS / RS / RT
Issue	7/95 – rev.00

Recommended siting	Under the fuel tank in front of the battery.
Power supply	Connect the positive supply wire of the alarm system to the WHITE/RED wire of the 4-way black connector behind the steering post. Connect the negative supply wire to a screw on the frame.
Engine immobilisation (1)	Follow diagram B. Cut the GREEN/YELLOW wire of the 12-way black connector of the right switch.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/BLACK wire of the 12-way black connector of the right switch.
Ignition controlled positive supply	Connect to the GREEN wire of the 8-way orange connector of the key switch.
Turn indicators	Connect to the BLUE/BLACK wire and RED/BLUE wire of the 12-way white connector over the black connector of the right switch.