


Motorcycle Manufacturer	
Model	R 1200 C
Issue	05/98 – rev. 00

Recommended siting	Under the fuel tank, in front of the battery.
Power supply	Connect the positive supply wire of the alarm system to the RED wire of the orange 8-way connector found in the connector-box, under the “Motronic” unit. Connect the negative supply wire of the alarm system to an earth bolt on the frame.
Engine immobilisation (1)	Follow diagram B. Cut the GREEN/YELLOW wire (0,50 mm) of the black 10-way connector placed in the connector-box, under the “Motronic” unit.
Engine immobilisation (2)	Cut the BLACK/YELLOW wire of the black 10-way connector placed in the connector-box, under the “Motronic” unit.
Ignition controlled positive supply	Connect to the GREEN wire of the orange 8-way connector placed in the connector-box, under the “Motronic” unit.
Turn indicators	Connect to the BLUE/BLACK wire and BLUE/RED wire of the light blue 18-way connector placed in the connector-box, under the “Motronic” unit.