


Motorcycle Manufacturer	
Model	ELEFANT 750/900
Issue	4/95 – rev. 00

Recommended siting	On the right side. Secure the alarm unit to one of the screws of the turn indicator.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire to the BLUE wire of the key switch.
Engine immobilisation (1)	Follow diagram B. Cut the WHITE/RED wire of the key switch.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire of the right switch.
Ignition controlled positive supply	Connect to the GREEN/BLACK wire of the key switch.
Turn indicators	Connect to the RED/BLACK and LIGHT BLUE wires of the connector of the left switch.