


Motorcycle Manufacturer	
Model	GRAND CANYON 900
Year	//
Issue	05/99 – rev. 00

Recommended siting	Install the alarm system below the fender, under the rear carrier, between the fuse-box and the tail light.
Power supply	Connect the positive supply wire of the alarm system to the RED wire available in the connector of the yellow relay, near the tail light. Connect the negative supply wire of the alarm system to the o.e. earth point on the electronic control unit located near the fuse-box.
Engine immobilisation (1)	Follow diagram B. Cut the RED/GREEN wire available in the connector of the yellow relay, near the tail light.
Ignition controlled positive supply	Connect to the RED/GREEN wire available in the connector of the yellow relay, near the tail lamp. This is the same wire as used for engine immobilisation.
Turn indicators	Connect to the RED/BLACK wire and LIGHT BLUE wire available in the white 6-way connector found behind the tail light.