


Motorcycle Manufacturer	
Model	RIVER 600
Issue	6/95 – rev. 00

Recommended siting	Inside the rear left side.
Power supply	Connect the positive and the negative supply wires of the alarm system to the battery.
Engine immobilisation (1)	Follow diagram B. Cut the WHITE/RED wire of the ignition unit placed under the fuel tank behind the steering post.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire on the solenoid located on the right of the battery.
Ignition controlled positive supply	Connect to the GREEN/BLACK wire of the flasher unit.
Turn indicators	Connect to the RED/BLACK and LIGHT BLUE wires of the rear indicators.