



Motorcycle Manufacturer	<i>DUCATI</i>
Model	Hypermotard
Issue	09/07 rev. 00

Recommended siting	Secure the alarm unit behind the front left side fairing, via the original perforated wings that are welded to the frame.
Power supply	Connect the positive and negative supply wires of the alarm unit to the positive and negative terminals of the motorcycle's battery.
Engine immobilisation (1)	The bike is originally equipped with an immobiliser.
Engine immobilisation (2)	Cut the BLUE/BLACK wire available in the 4-way red plug that is connected to the starter solenoid, under the seat on the right side.
Ignition controlled positive supply	Connect to the RED/WHITE wire available in the 4-way black plug that is connected to the harness exiting the ignition lock (it is secured to the frame behind the steering column on the left side).
Turn indicators	Connect one of the yellow wires of the security system to the YELLOW wire found in the 3-way black plug that is secured to the rear frame, close to the tail light.