



Motorcycle Manufacturer	<i>DUCATI</i>
Model	ST 2 / ST 4 / SS 98
Issue	04/99

Recommended siting	Over the battery.
Power supply	Connect the positive supply wire and the negative supply wire of the alarm system directly to the terminals of the motorcycle battery.
Engine immobilisation (1)	Follow diagram B. Cut the BLUE/YELLOW wire available in the 6-way connector of the harness coming out of the ignition lock, behind the battery.
Engine immobilisation (2)	Follow diagram B. Cut the BLUE/RED wire of the starter solenoid placed in front of the battery.
Ignition controlled positive supply	Connect to the same BLUE/YELLOW wire as used for engine immobilisation 1.
Turn indicators	Connect to the WHITE/GREEN wire and WHITE/BLACK wire available on the front turn indicators.