


Motorcycle Manufacturer	
Model	DNA
Issue	02/01 – rev. 00

Recommended siting	Under the seat, behind the battery.
Power supply	<p>Locate the 14-way connector placed under the seat, behind the battery.</p> <p>Connect the positive supply wire of the alarm system to the RED wire available in pos. 08 of the 14-way connector.</p> <p>Connect the negative supply wire of the alarm system to the BLACK wire available in pos.02 of the 14-way connector.</p>
Engine immobilisation (1)	Follow diagram A. Connect to the GREEN wire available in pos. 12 of the 14-way connector, placed under the seat, behind the battery.
Engine immobilisation (2)	//
Ignition controlled positive supply	Connect to the WHITE wire available in pos. 04 of the 14-way connector, placed under the seat, behind the battery.
Turn indicators	Connect to the PINK wire and WHITE/BLUE wire available in pos. 01 and pos.09 of the 14-way connector, placed under the seat, behind the battery.
LED connection	<p>Connect the BROWN/WHITE wire of the alarm system to the RED/BLACK wire placed in pos. 13 of the 14-way connector.</p> <p>Connect the BLACK wire of the LED to the RED/BLACK wire available in the grey 2-way connector placed under the instruments.</p> <p>Connect the RED wire of the LED to the RED wire of the 16-way connector that is attached to the instruments.</p>