


Motorcycle Manufacturer	
Model	TYPHOON 50/125, STORM 50, STALKER, RUNNER 50/180
Issue	06/98 – rev.00

Recommended siting	Behind the front shield.
Power supply	Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire to the BLACK wire of the key switch.
Engine immobilisation (1)	Follow diagram A. Connect to the GREEN wire of the key switch.
Engine immobilisation (2)	Follow diagram B. Cut the GREEN/BLACK wire in the wiring loom coming down from the handle-bar.
Ignition controlled positive supply	Connect to the WHITE wire of the key switch.
Turn indicators	Connect to the PINK and BLUE/WHITE wires of the wiring loom coming down from the handle- bar.