


Motorcycle Manufacturer	 MOTO GUZZI
Model	850 T5
Issue	7/95 – rev. 00

Recommended siting	Under the instruments on the right side.
Power supply	Connect the positive supply wire of the alarm system to the RED/GREEN wire of the clock and the negative supply wire to the BLACK wire of a turn indicator warning light.
Engine immobilisation (1)	Follow diagram B. Cut the WHITE wire of the connector of the right switch.
Engine immobilisation (2)	Follow diagram B. Cut the WHITE wire of the connector of the right switch.
Ignition controlled positive suppli	Connect to the RED wire of the voltmeter.
Turn indicators	Connect to the wires of the turn indicator warning lights.