


| | |
|--------------------------------|---|
| Motorcycle Manufacturer |  MOTO GUZZI |
| Model | CALIFORNIA |
| Issue | 06/99 – rev. 00 |

| | |
|--|--|
| Recommended siting | Under the seat, behind the glove compartment. |
| Power supply | Connect the positive and the negative supply wires of the alarm directly to the battery. |
| Engine immobilisation (1) | Follow diagram B. Cut the BROWN/WHITE wire available in the connector of the ignition relay (the second one on the right), placed behind the right side fairing. |
| Engine immobilisation (2) | Cut the WHITE/BLACK wire available in the connector of the starter relay (the first one on the left), placed behind the right side fairing. |
| Ignition controlled positive supply | Connect to the BLUE/BLACK wire available in the connector of the warning horn relay (the second one on the left), placed behind the right side fairing. |
| Turn indicators | Connect to the PINK wire and BLACK/GREEN wire available in the black round 3-way connector, placed behind the battery, towards the fender. |