


Motorcycle Manufacturer	 MOTO GUZZI
Model	NEVADA
Issue	07/02 – rev. 00

Recommended siting	Fix the the alarm on the battery, via the o.e. elastic band that fastens the battery.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the WHITE/BROWN wire available in the connector of the relay placed on the right of the battery (the one near the fuses), behind the right side fairing.
Engine immobilisation (2)	Cut the WHITE/BLACK wire available in the connector of the starter rela, on the right of the battery (the relay near the turn indicator flasher unit), behind the right side fairing.
Ignition controlled positive supply	Connect to the WHITE/BLUE wire on the 15A-fuse (the first on the left) found in the fuse-box behind the right side fairing.
Turn indicators	Connect to the PINK wire and GREEN/BLACK wire available in the white 6-way connector placed under the seat.