


Motorcycle Manufacturer	 HONDA
Model	@
Issue	06/2000 – rev. 00

Recommended siting	Under the front shield, between the relays and the headlamp.
Power supply	Connect the positive supply wire of the alarm system to the RED wire available in the white 3-way connector of the harness that comes out of the ignition lock. Connect the negative supply wire of the alarm system to the GREEN wire of the 9-way connector in the rubber boot, on the right of the headlamp.
Engine immobilisation (1)	Follow Diagram B. Cut the RED/BLACK wire of the 3-way connector of the wiring harness coming out of the ignition lock.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 4-way white connector that is located inside the rubber boot on the right of the headlamp.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the 3-way connector of the harness coming out of the ignition lock (the same wire as used for Engine Immobilisation 1).
Turn indicators	Connect to the ORANGE wire and LIGHT BLUE wire available in the 9-way connector that is located inside the rubber boot on the right of the headlamp.