


Motorcycle Manufacturer	
Model	AFRICA TWIN 750
Issue	12/98 – rev. 00

Recommended siting	On the right side of the rear frame.
Power supply	Connect the positive and the negative supply wires of the alarm system to the terminals of the motorcycle battery.
Engine immobilisation (1)	Follow diagram B. Cut the WHITE wire of the 4-way connector available in the connector-holder, on the left of the ignition unit.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire found in the 4-way connector of the starter solenoid.
Ignition controlled positive supply	Connect to the RED wire of the red 3-way connector available in the connector-holder on the left of the ignition unit.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available inside the rubber protection boot behind the right fairing.