


Motorcycle Manufacturer	 HONDA
Model	CB 500
Issue	04/98 – rev. 00

Recommended siting	Under the seat, behind the tail light.
Power supply	Connect the positive and the negative supply wires of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow Diagram B. Cut the YELLOW wire of the white 4-way connector that is available inside the rubber protection boot behind the right fairing, near the starter solenoid.
Engine immobilisation (2)	Cut the YELLOW/RED wire found in the red 4-way plug that is connected to the starter solenoid.
Ignition controlled positive supply	Connect to the GREEN/WHITE wire of the white 2-way connector. This connector is available inside the rubber protection boot behind the right frame, near the starter solenoid.
Turn indicators	Connect to the ORANGE wire and LIGHT BLUE wire of the rear turn indicators.