


Motorcycle Manufacturer	 HONDA
Model	CB 1300
Issue	05/04 Rev. 00

Recommended siting	Behind the right rear fairing.
Power supply	Connect the positive supply wire of the alarm system to the RED/GREEN wire available in the 6-way connector behind the tail light. Connect the negative supply wire of the alarm system to the GREEN wire available in the same connector.
Engine immobilisation (1)	Cut the BLACK/WHITE wire in the 4-way black connector of the fuel pump relay, behind the left rear fairing.
Ignition controlled positive supply	Cut the YELLOW/RED wire available in the 4-way red connector of the starter solenoid, under the right fairing close to the fuel tank.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available in the 6-way connector behind the tail light.

Remark: to avoid backfeeds through the turn indicators, it is recommended to fit a diode to the WHITE/GREEN wire available in the 3-way black plug that is connected to the flasher unit, behind the tail light on the right side.

