


Motorcycle Manufacturer	 HONDA
Model	CBF 600
Issue	02/04 Rev. 00

Recommended siting	Behind the right rear fairing.
Power supply	Connect the positive supply wire of the alarm system to the RED/GREEN wire available in the 6-way connector behind the left side fairing, under the regulator. Connect the negative supply wire of the alarm system to the GREEN wire available in the same connector.
Engine immobilisation (1 and 2)	Cut the GREEN wire available in the 3-way white connector inside the transparent rubber protection boot, behind the black side fairing that is secured under the fuel tank.
Ignition controlled positive supply	Connect to the WHITE/BLACK wire found in the 6-way connector behind the left side fairing, under the regulator.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available in the 6-way connector behind the left fairing, under the regulator.