


Motorcycle Manufacturer	 HONDA
Model	CBF 1000
Issue	03/06 Rev. 00

Recommended siting	Behind the left rear fairing.
Power supply	Connect the positive supply wire of the alarm system to the RED/GREEN wire available in the 6-way connector behind the right rear fairing. Connect the negative supply wire of the alarm system to the GREEN wire available in the same connector.
Engine immobilisation (1)	Cut the YELLOW wire available in the red 2-way connector that is secured to the frame on the right side, behind the radiator.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 4-way connector of the starter solenoid, behind the front right fairing.
Ignition controlled positive supply	Connect to the WHITE/BLACK wire found in the 6-way connector behind the right rear fairing.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available in the 6-way connector behind the right rear fairing.