


Motorcycle Manufacturer	 HONDA
Model	CBR 600 RR ym 2003 >
Issue	03/03 Rev. 00

Recommended siting	Behind the rear right fairing, inside the tool compartment.
Power supply	Connect the positive supply wire of the alarm system to the RED/GREEN wire in the 6-way connector located behind the battery, under the seat on the left. Connect the negative supply wire of the alarm system to the GREEN wire in the same connector.
Engine immobilisation (1)	The bike is fitted with an o.e. immobiliser.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 4-way red connector of the starter solenoid, behind the battery.
Ignition controlled positive supply	Connect to the WHITE/BLACK wire found in the 6-way connector located behind the battery, under the seat on the left.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available in the 6-way connector located behind the battery, under the seat on the left.

Remark: to avoid backfeeds through the turn indicators, it is recommended to fit a diode to the GREY wire found in the 14-way light blue plug under the fairing on the left of the fuel tank.

