


Motorcycle Manufacturer	 HONDA
Model	CBR 600 ym 98 >
Issue	01/99 – rev. 00

Recommended siting	On the rear frame, in front of the CDI, under the left fairing.
Power supply	Connect the positive supply wire and the negative supply wire of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the YELLOW wire with black dots available in the connector of the cdi, under the left fairing.
Engine immobilisation (2)	Cut the YELLOW-RED wire available in the red 4-way plug that is connected to the starter solenoid, on the left of the battery.
Ignition controlled positive supply	Connect to the BROWN/BLACK wire available in the white 2-way connector placed behind the battery.
Turn indicators	Connect to the ORANGE wire and LIGHT BLUE wire of the rear turn indicators.