


<b>Motorcycle Manufacturer</b>	 <b>HONDA</b>
<b>Model</b>	<b>CBR 900</b>
<b>Year</b>	//
<b>Issue</b>	<b>01/99 – rev. 00</b>

<b>Recommended siting</b>	Install the alarm system under the seat, behind the battery or on the left side of the rear frame, behind the fairing.
<b>Power supply</b>	Connect the positive and the negative supply wires of the alarm system directly to the battery.
<b>Engine immobilisation (1)</b>	Follow diagram B. Cut the BLACK/WHITE wire available in the connector of the CDI, behind the battery.
<b>Engine immobilisation (2)</b>	Cut The YELLOW/RED wire available in the connector of the starter solenoid placed on the right of the battery.
<b>Ignition controlled positive supply</b>	Connect to the WHITE/GREEN wire available in the white 2-way connector that is placed on the right of the battery.
<b>Turn indicators</b>	Connect to the ORANGE wire and to the LIGHT BLUE wire available in the white 6-way connector placed behind the right fairing.