




| | |
|--------------------------------|---|
| Motorcycle Manufacturer |  |
| Model | CBR 900 |
| Issue | 11/96 – rev. 00 |

- Recommended siting** Under the seat behind the battery or on the left side of the rear frame.
- Power supply** Connect the positive and the negative supply wires of the alarm system to the battery.
- Engine immobilisation (1)** Follow diagram B. Cut the BLACK/WHITE wire of the ignition unit.
- Engine immobilisation (2)** Follow diagram B. Cut the YELLOW/RED wire of the starter solenoid.
- Ignition controlled positive supply** Connect to the BLACK wire of the 2-way connector of the rear stop light switch..
- Turn indicators** Connect to the ORANGE and LIGHT BLUE wires of the rear turn indicators.