


Motorcycle Manufacturer	 HONDA
Model	CBR 1000
Issue	7/95 – rev. 00

Recommended siting	Under the seat, in the tail behind the rear lamp.
Power supply	Connect the positive and the negative supply wires of the alarm system to the battery.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/WHITE wire of the ignition unit.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire of the solenoid.
Ignition controlled positive supply	Connect to the BLACK wire of the intermittence.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires of the rear turn indicators.