


Motorcycle Manufacturer	 HONDA
Model	CBR 1000 RR
Issue	02/04 Rev. 00

Recommended siting	Under the tail fairing on the left.
Power supply	Connect the positive supply wire of the alarm system to the RED/GREEN wire in the 6-way plug that is located behind the battery, under the seat on the left. Connect the negative supply wire of the alarm system to the GREEN wire in the same connector.
Engine immobilisation (1)	The bike is fitted with an o.e. immobiliser.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 4-way red connector of the starter solenoid, behind the battery.
Ignition controlled positive supply	Connect to the WHITE/BLACK wire available in the 6-way connector that is located behind the battery, under the seat on the left.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available in the 6-way connector behind the battery, under the seat on the left.

Remark: to avoid backfeeds through the turn indicators, it is recommended to fit a diode to the GREY wire available in the 10-way white plug in front of the air filter under the electronic steering shock absorber.

