


Motorcycle Manufacturer	 HONDA
Model	CBR 1100 XX
Issue	11/96 – rev. 00

Recommended siting	Under the plastic panel on the left of the instruments.
Power supply	Connect the positive supply wire of the alarm system to the RED wire of the 3-way white connector and the negative supply wire of the alarm system to the GREEN wire of the 9-way black connector available under the plastic cover on the right of the instruments.
Engine immobilisation (1)	Follow Diagram B. Cut the BLACK/WHITE wire of the red 9-way connector located under the plastic cover on the right of the instruments.
Engine immobilisation (2)	Follow Diagram B. Cut the YELLOW/RED wire of the red 9-way connector available under the plastic panel on the right of the instruments.
Ignition controlled positive supply	Connect to the RED/BLACK wire of the 3-way white connector located under the plastic cover on the right of the instruments.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires of the black 9-way connector found under the plastic panel on the right of the instruments.