


Motorcycle Manufacturer	 HONDA
Model	CBR 1100 XX ym 99 >
Issue	02/99 – rev. 00

Recommended siting	Install the alarm box over the electronic control unit placed behind the tail light, under the fairing.
Power supply	Connect the positive and negative supply wires of the alarm system directly to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/WHITE wire available in the 4-way connector of the fuel pump relay, under the seat behind the battery (the one in the middle).
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 4-way red connector of the starter solenoid, on the left of the battery.
Ignition controlled positive supply	Connect to the WHITE/GREEN wire available in the white 2-way connector placed on the right of the battery.
Turn indicators	Connect to the ORANGE wire and LIGHT BLUE wire available inside the rubber protection boot placed behind the rear light, on the right.