




Motorcycle Manufacturer	 HONDA
Model	CN 250
Issue	7/95 – rev. 00

- Recommended siting** Under the front shield on the left side.
- Power supply** Connect the positive supply wire of the alarm system to the RED wire and the negative supply wire to the GREEN wire available in the connector box behind the hand brake control.
- Engine immobilisation (1)** Follow diagram A. Connect to the BLACK/WHITE wire available in the connector box behind the hand brake control.
- Engine immobilisation (2)** Follow diagram B. Cut the YELLOW/RED wire available in the connector box behind the hand brake control.
- Ignition controlled positive supply** Connect to the BLACK wire available in the connector box behind the hand brake control.
- Turn indicators** Connect to the ORANGE and LIGHT BLUE wires available in the connector box behind the brake control.