

Motorcycle Manufacturer	HONDA
Model	FORESIGHT 250
Issue	10/97 – rev. 00

Recommended siting Under the front shield.

Power supplyConnect the positive supply wire of the alarm system

to the RED wire of the black 2-way connector of the ignition lock. Connect the negative supply wire of the

alarm system to an earth bolt on the chassis.

Engine immobilisation (1) Follow Diagram B. Cut the RED/BLACK wire of the

black 2-way connector in the harness that comes out

of the ignition lock.

Ignition controlled positive

supply

Connect to the same RED/BLACK wire as used for

engine immobilisation.

Turn indicatorsConnect to the ORANGE wire and LIGHT BLUE wire

of the 6-way brown connector located on the plastic surface behind the front shield, under the handle-bar.