


Motorcycle Manufacturer	 HONDA
Model	HORNET 600 CB ym 2003 >
Issue	03/03 Rev. 00

Recommended siting	Behind the rear right fairing, inside the tool compartment.
Power supply	Connect the positive supply wire of the alarm system to the RED/GREEN wire in the 6-way connector located under the CDI, under the seat on the left side. Connect the negative supply wire of the alarm system to the GREEN wire in the same connector.
Engine immobilisation (1)	The bike is fitted with an o.e. immobiliser.
Engine immobilisation (2)	Cut the YELLOW/RED wire found in the 4-way red connector of the starter solenoid, behind the right fairing under the seat.
Ignition controlled positive supply	Connect to the WHITE/BLACK wire available in the 6-way connector found under the CDI, under the seat on the left.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires found in the 6-way connector under the CDI, under the seat on the left.