


Motorcycle Manufacturer	 HONDA	
Model	PANTHEON 125 – 150 ym 2003 >	
Issue	08/03	Rev. 01

Recommended siting	Under the front shield on the right, over the tool compartment.
Power supply	Connect the positive supply wire of the security system to the GREEN/BLACK wire found in the 9-way red plug that is located inside the transparent rubber protection boot over the ignition lock. Connect the negative supply wire of the security system to the GREEN wire found in the 2-way white connector of the right turn indicator.
Engine immobilisation (1)	Follow diagram B. Cut the YELLOW/RED wire found in the 9-way white connector inside the transparent rubber protection boot over the ignition lock.
Ignition controlled positive supply	Connect to the RED/BLACK wire found in the 9-way red connector inside the transparent rubber protection boot over the ignition lock.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires found in the 9-way white connector inside the transparent rubber protection boot over the ignition lock.

Remark: to avoid backfeeds through the turn indicators, it is recommended to fit a diode to the BROWN/BLACK wire found in the 3-way white plug that is connected to the flasher unit, under the instruments.

