


Motorcycle Manufacturer	 HONDA
Model	PC 800
Issue	7/97 – rev. 00

Recommended siting	Secure the alarm vertically in front of the rear case, behind the battery.
Power supply	Connect the positive and the negative supply wires of the alarm system to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/WHITE wire of the ignition unit.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire found in the red 4-way plug that is connected to the starter solenoid.
Ignition controlled positive supply	Connect to the BLACK wire of the flasher unit.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires of the rear turn indicators.