


Motorcycle Manufacturer	 HONDA
Model	SFX 50 e X8R-R/Z
Issue	12/98 – rev. 00

Recommended siting

Under the front shield.

Power supply

Connect the positive supply wire of the alarm system to the RED wire of the 2-way connector in the harness that comes out of the ignition switch. Connect the negative supply wire to the screw that holds the regulator.

Engine immobilisation (1)

Follow diagram B. Cut the RED/BLACK wire found in the 2-way connector of the harness that comes out of the ignition switch.

Engine immobilisation (2)

Cut the YELLOW/RED wire of the 2-way connector in front of the steering post.

Ignition controlled positive supply

Connect to the RED/BLACK wire found in the 2-way connector of the harness that comes out of the ignition switch (same wire as engine immobilisation 1).

Turn indicators

Connect to the ORANGE and LIGHT BLUE wires of the 2-way connectors of the front turn indicators.