


<b>Motorcycle Manufacturer</b>	 <b>HONDA</b>
<b>Model</b>	<b>SH 50</b>
<b>Issue</b>	<b>10/96 – rev. 00</b>

<b>Recommended siting</b>	Under the front shield.
<b>Power supply</b>	Connect the positive supply wire of the alarm system to the RED wire of the 2-way connector that comes out of the key switch; connect the negative supply wire to the screw that holds the regulator.
<b>Engine immobilisation (1)</b>	Follow diagram B. Cut the RED/BLACK wire found in the 2-way connector that comes out of the key switch.
<b>Engine immobilisation (2)</b>	Follow diagram B. Cut the YELLOW/RED wire of the 6-way connector available in front of the steering post.
<b>Ignition controlled positive supply</b>	Connect to the RED/BLACK wire found in the 2-way connector that comes out of the ignition switch (see engine immobilisation 1).
<b>Turn indicators</b>	Connect to the ORANGE and LIGHT BLUE wires of the 9-way connector of the front turn indicators.