


Motorcycle Manufacturer	 HONDA
Model	SH 125/150
Issue	05/01 – rev. 00

Recommended siting	Install the alarm system under the front shield, on the right of the radiator.
Power supply	Connect the positive wire of the alarm system to the RED wire available in the white 3-way connector of the harness coming out of the ignition lock. This connector is sited inside the rubber protection boot over the left side of the radiator. Connect the negative supply wire of the alarm system to the earth point available under the radiator fan.
Engine immobilisation (1)	Follow Diagram B. Cut the RED/BLACK wire found in the white 3-way connector in the loom coming out of the ignition lock. This is available inside the rubber protection boot over the left side of the radiator.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the white 4-way connector found inside the rubber protection boot, over the right side of the radiator.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the white 3-way connector of the harness coming out of the ignition lock. This is the same wire as used for Engine Immobilisation (1).
Turn indicators	Connect to the ORANGE wire and to the LIGHT BLUE wire available in the white 9-way connector placed in the rubber protection boot over the right side of the radiator.