


Motorcycle Manufacturer	 HONDA
Model	SILVER WING 400 – 600
Issue	03/06 – rev. 01

Recommended siting	Install the security unit behind the headlamp on the left side. Secure it to the metal frame.
Power supply	Connect the positive supply wire of the alarm system to the RED wire of the white 3-way connector that is attached to the harness of the ignition lock, inside the rubber protection boot behind the front left turn indicator. Connect the negative supply wire of the alarm system to a bolt on the frame.
Engine immobilisation (1)	Follow Diagram B in the installation manual of the security system. Cut the BLACK/WHITE wire in the white 9-way connector that is placed in the rubber protection boot behind the front left turn indicator.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the red 9-way connector that is located inside the rubber protection boot behind the front left turn indicator.
Ignition controlled positive supply	Connect to the BLACK/BROWN wire available in the white 9-way connector that is placed in the rubber protection boot behind the front left turn indicator.
Turn indicators	Connect to the ORANGE wire and LIGHT BLUE wire available in the brown 6-way connector that is secured to the plastic panel behind the instruments, under the front shield.

NOTE: if you wish to protect the seat against unauthorised opening, connect the **BLUE** wire / wire n. 4 of the alarm system to the **LIGHT GREEN** wire of the tool compartment courtesy light.