


Motorcycle Manufacturer	 HONDA
Model	VARADERO
Year	//
Issue	02/99 – rev. 00

Recommended siting	Under the plastic panel on the left of the instruments.
Power supply	Connect the positive supply wire of the alarm system to the RED wire available in the white 3-way connector placed inside the rubber protection on the left radiator. Connect the negative supply wire of the alarm system to the GREEN wire available in the white 2-way connector placed on the left of the instruments.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/WHITE wire available in the red 6-way connector placed inside the rubber protection, on the left radiator
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the red 6-way connector placed inside the rubber protection on the left radiator.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the white 3-way connector that is placed inside the rubber protection boot over the left radiator.
Turn indicators	Connect to the ORANGE wire and to the LIGHT BLUE wire available in the black 9-way connector that is found inside the rubber protection over the left radiator.