


Motorcycle Manufacturer	 HONDA
Model	VARADERO with ABS ym 04 >
Issue	03/04 Rev. 00

Recommended siting	Remove the black plastic wall on the left of the instruments over the left radiator and secure the alarm unit in front of the CDI via the elastic band that holds the CDI.
Power supply	Connect the positive supply wire of the alarm system to the RED wire available in the white 4-way connector sited inside the rubber protection boot over the left radiator. Connect the negative supply wire of the alarm system to the GREEN wire available in the 2-way black connector over the left radiator.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/WHITE wire available in the 6-way connector of the harness that powers the right switch, under the right side of the fuel tank.
Engine immobilisation (2)	Cut the YELLOW/RED wire found in the 6-way connector of the harness that powers the right switch, under the right side of the fuel tank.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the white 4-way connector inside the rubber protection boot over the left radiator.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available in the 9-way black connector inside the rubber protection boot over the left radiator.