


Motorcycle Manufacturer	 HONDA
Model	VARADERO ym 2003 >
Issue	02/03 Rev. 00

Recommended siting	Remove the black plastic cover on the left of the instruments over the left radiator and secure the alarm unit in front of the CDI. Use the the elastic band that holds the CDI.
Power supply	Connect the positive supply wire of the security system to the RED wire found in the 4-way white connector inside the rubber protection boot over the left radiator. Connect the negative supply wire of the GREEN wire available in the 2-way black connector over the left radiator.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/BROWN wire available inside the 6-way red plug that is located inside the rubber protection boot over the right radiator.
Engine immobilisation (2)	Cut the YELLOW/RED wire available in the 6-way red plug that is located inside the rubber protection boot over the right radiator.
Ignition controlled positive supply	Connect to the RED/BLACK wire available in the white 4-way plug that is located inside the rubber protection boot over the left radiator.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires available in the black 9-way plug that is located inside the rubber protection boot over the left radiator.