


Motorcycle Manufacturer	 HONDA
Model	VFR 750, CBR 1000, NTV 650
Issue	7/95 – rev. 00

Recommended siting	Under the seat, in the tail compartment, behind the rear lamp.
Power supply	Connect the positive and the negative supply wires of the alarm system to the battery terminals.
Engine immobilisation (1)	Follow diagram B. Cut the BLACK/WHITE wire of the ignition unit.
Engine immobilisation (2)	Follow diagram B. Cut the YELLOW/RED wire found in the 4-way red plug that is connected to the starter solenoid.
Ignition controlled positive supply	Connect to the BLACK wire of the flasher unit.
Turn indicators	Connect to the ORANGE and LIGHT BLUE wires of the rear turn indicators.